

## Display Specification

09/2018

---

**Product :** Middle Type Intelligent LCD Display

**Model :** APT12LCD800S –UART -5S

**Abbreviation :** 800S-UART

---

**Client :**

**Customer audit :**

---

**Supplier :** Tianjin APT Science and Technology Co., Ltd.  
1001, Building 5 HuaDing, No.1 HuaKe 3 Road, Binhai hi-tech Industrial Development Zone, Tianjin, China  
TEL:+86 22 26345859  
FAX:+86 22 83719955

**Email :** [yzhao@aptdevelop.com](mailto:yzhao@aptdevelop.com)

## 1 . Product Name

The Middle type intelligent LCD Display, model number as APT12LCD800S-UART-5S.

## 2 . Supplier Tianjin APT Science and Technology Co., Ltd.

## 3 . Electrical Parameters

- ✧ 24V/36V/48V/52V battery output
- ✧ Rated operating current : 10mA
- ✧ Max operating current : 30mA
- ✧ Off leakage current < 1uA
- ✧ Output controller working current: 50mA
- ✧ Operating temperature : -30 ~ 70 °C
- ✧ Storage temperature : -40 ~ 70 °C

## 4 . Dimensions & Materials

Display shell is ABS, transparent window is made with high strength Acrylic with stiffness equals as the tempered glass.

Dimensions : L90mm \* W54mm \* H13.3mm




## 5 . Features


- ✧ Suitable for low temperature, Max -30 °C.
- ✧ Ergonomic external button design, easy to operate.
- ✧ Speed display: AVG SPEED, MAX SPEED, AVERAGE SPEED(Real-time).
- ✧ Kilometer/ Mile : Can be set as per customers' habits.
- ✧ 9-level Assit : Up to users' habit.
- ✧ Mileage indicator : Max trip distance(max 99,999.9)/ Odometer /Riding time
- ✧ Parameter settings: Multiple parameters can be set through computer USB port, including Assist level / Wheel diameter / Voltage / Speed limit, etc. For detailed, pls refer to separate computer parameter setting files.

## 6 . LCD instructions

LCD display shown as below:



## 7 . Function Description




### 7.1 Power On/Off

Press and hold **Power** button for 1 second, then display will work and controller power supply turn on. During the working mode, if press and hold **Power** button for 1 second, then display will stop and controller output will be cut off. If no further action to display within 5 minutes(could be set), display will cut off automatically and power output cut off.

### 7.2 Assist level selecting

Short press **UP/DOWN** button to change the assist level. Top assist level is 9, 1 is the lowest, when display turn on, automatically it will be level 1. 0 level is without any assistance.




Assist operation manual

### 7.3 Speed mode switch& Mileage mode switch

Short press **POWER** button can switch change the speed mode & mileage mode, data sequence is as:

Average Speed->Max Speed->Actual Speed->Single Trip->ODO-> Time.




Speed Mode & Mileage mode Interface

\*If there is no operation for 5 seconds, display will return to Speed (Real-Time) display automatically.


#### 7.4 Headlight/backlight On/Off

Press and hold **UP** button for 1 second , then headlight/backlight will turn on, if press **UP** button for 1 second again, then display backlight/headlight will turn off.



#### 7.5 Battery Capacity Indication

5 bars in display to show battery capacity, if battery under voltage, then no bar in display, then battery needs to be charged immediately.




## 7.6 Parameter Setting


When system turn on, double press **POWER** button (press interval <0.3 second) can get into parameter setting state, under this, parameter could be set. And double press **POWER** button (press interval <0.3 second) to exit. In parameter setting state, when flashing, press **UP/DOWN** buttons to adjust parameters, short press **POWER** button to switch parameter items.

\*The display will automatically exit parameters setting state if no operation for 10 seconds.


The order of parameters is as follows.




✧ **Data cleanup** : The location of speed displays symbol Cr , press **UP/DOWN** button to change no or yes.




✧ **Kilometer / Mile** : The location of speed displays symbol S7, press **UP/DOWN** button to change between **km/h / MPH** (**Km / Mile**).




✧ **Backlight brightness** : The location of speed displays symbol **bl1**, press **UP/DOWN** button display symbol **1~5** to change the brightness of the backlight. 1-darkest, 5-brightest.




✧ **Auto off time** : The location of speed displays symbol **OFF**, press **UP/DOWN** button to change the value from **0** to **15**, the number represent delay time (minutes) before display shutdown automatically.



✧ **Wheel diameter:** The location of speed displays symbol **Wd**, press **UP/DOWN** button to change between **16/18/20/22/24/26/27/28/700C/29**, value represents the diameter of the wheel (inch). Wrong value for wheel diameter will cause speed & mileage abnormal.




✧ **Voltage Setting :** The location of speed displays symbol **bU0**, press **UP/DOWN** button to switch between **24V/36V/48V//52V/UbE**, **UbE** means user-defined voltage setting, this parameter can be set through computer.




✧ **Password/Speed Limit Setting :** The location of speeds displays symbol **PSd**, require to input passwords, press **UP/DOWN** buttons to change the password value (0~9), short press **POWER** button



to switch the password item, password is 4 digits, the default password is "1919". Press **POWER** button when password adjustment is completed. Display will return to the **Voltage set** item if the password is incorrect. Correct password will enter the **Speed Limit Setting** item.




✧ **Speed Limit Setting** : The location of speed displays symbol **SPL**, the location of mileage displays speed limit value, the default value is **25km/h**. Press **UP/DOWN** buttons to modify the value, the value can be set from 10 to 41km/h. Short press **POWER** button to enter the next item.




The maximum speed is restricted by the motor and controller, probably couldn't reach the setting value.


✧ **Magnetic Pole numbers of speed sensor** : The location of speed displays symbol **HAL**, the location of mileage displays magnetic pole number, press **UP/DOWN** buttons to modify the value. When setting finished, short press **POWER** to enter next setting.




✧ **Direction of speed sensor:** The location of speed displays symbol **ASd**, press **UP/DOWN** button rotate display symbol **0/1**, 0 indicates forward, 1 indicates backward. When setting finished, short press **POWER** to enter next setting.




✧ **Power Assistance Start Over Set Magnet Qty:** The location of speed displays symbol **SAS**, the location of mileage shows pole number, press **UP/DOWN** buttons to modify the when power assistance start after certain qty of magnet. When setting finished, short press **POWER** to enter next setting.




✧ **Assistance level:** The location of speed displays symbol **ASr**, the location of mileage shows assistance level value, press **UP/DOWN** buttons to modify the value. When setting finished, short press **POWER** to enter next setting.




- ✧ **Throttle set** : The location of speed displays symbol **HdP**, press **UP/DOWN** button shows symbol **0~1** to change the throttle OFF or ON. When setting finished, short press **POWER** to enter next setting.




- ✧ **Throttle 6KM set** : The location of speed displays symbol **Hd6**, press **UP/DOWN** button shows symbol **0~1** to change the throttle 6km OFF or ON. When setting finished, short press **POWER** to enter next setting.




- ✧ **Slow startup parameters**: The location of speed displays symbol **Sdr**, the location of mileage displays value, press **UP/DOWN** button to modify the value.




✧ **MAX Current Limit set:** The location of speed displays symbol **CUL**, the location of mileage displays current limit value, the default value is **15A**. Press **UP/DOWN** button to modify the value. When setting finished, short press **POWER** to enter next setting.




✧ **Range of assist level setting:** The location of speed displays symbol **PAS**, the location of mileage displays assist range, the default is **UBE**. Press **UP/DOWN** button to change the value from **0-3** to **UBE**.



## 8 . Error Code definition


800S-UART gives warning message when E-bike error, LCD display  icon and the error code in speed position area, error code is from 21 E~30 E, the error codes definition as below table:

Error Code	Error description	Handle
0x21	Current abnormal	/
0x22	Throttle error	Check turn to connect.
0x23	Motor phase lost	/
0x24	Motor hall error	Check the hall connection
0x25	Brake error	Check the brake connection.
0x30	Controller communication error	/



## 9 . Assembly Instructions

Please pay attention to the screw's torque value, damaged caused by excessive torque is not within the warranty.




There are 2 directions for the clamp installation, forward or backward.


Different assembly methods will need different cable length.



Clamps suit for 3 sizes of handlebar, 31.8mm, 25.4mm, 22.2mm, there are adaptor rings for 25.4mm and 22.2mm, adaptor ring must be assembled with the required directions, pay attention to the green arrow below.



## 10 . Output Wire Instructions



- 1、 Red wire : Anode(24V/36V/48V/52V) ;
- 2、 Blue wire : Power cord to the controller ;
- 3、 Black wire : GND ;
- 4、 Green wire : RxD (controller -> display) ;

5、 Yellow wire : TxD (display -> controller) ;

## 11 . Assistance Level Instructions

Assist level can be customized, the highest level is 9, common used assist level see the table below:

3 level	5 level	9 level	Description
0		0	No power assist
	1	1	
		2	
1	2	3	
		4	
	3	5	
2		6	
	4	7	
		8	
3	5	9	

## 12 . Certification

CE / IP65 (water proof) / ROHS.