

C. Screen setup

- To access the setup function of the computer: Press and hold the joystick to the left while squeezing the right-side brake lever. Press the battery power button to turn on the system, then continue to hold the joystick to the left and the brake lever closed for 3 seconds.

SET UNIT (km/h or mph)

0 sec | 10 sec

km/h (kilometers) | mph (miles)

Set unit: Press the joystick left or right to choose the desired unit (km/h or mph), then press the joystick down (center).

SET BACKLIGHT (yes or no)

BL Y | BL N

Backlight permanent | Backlight 5 seconds

Set backlight: Press the joystick left or right to choose the desired setting (backlight always on or 5 seconds), then press the joystick down (center).

TEMPERATURE / VERSION TEST

5 sec

TEMP 77F | VER 01

Temperature (mph=F) | Software version

TEMP 25C

Temperature (km/h=C)

Battery temperature / software version test: Press the joystick to the left for 5 seconds.

- Press the joystick to the right to switch between the temperature and the software version.
- Press the joystick to the left for 5 seconds to exit the test screen.

BATTERY VIEW OPTIONS

73% | 18%

Normal view | Low battery view

Battery view options: The screen will display the battery charge percentage until it drops below 20%, then it'll also show the battery symbol.

RESET TRIP MODE

3 sec

TRIP 73.1 | TRIP 0

Trip mode | Reset trip mode

Reset trip mode: When in TRIP mode, hold the joystick to the right for 3 seconds to reset. The TRIP mode will reset itself automatically after the battery is charged.