



## Basics

At a glance, the Pace 500 battery:

- Is attached to the downtube of the bike
- Is a Removable Lithium-ion 48V, 11.6Ah (556.8Wh)
- Weighs 7 lbs

### Turning Battery On

Quickly tapping the battery button once will turn the battery only on. The battery will first display one green indicator light, then change to up to 4. The four battery indicator lights indicate your ebike's current charge level, with each green light shown representing roughly 25% charge.

To turn your ebike on, press and hold either the power button or "M" button on the handlebar controls after you've quickly tapped the battery button on. Holding the power button will turn the Full Color Display on while holding the "M" button will turn on the M5 Display.

### Turning Battery Off

To turn your Pace 500 ebike system off, simply press and hold either the power or "M" button on your handlebar control for about 3-5 seconds.

### Charging and Charge Level Information

When charging, always plug the charging cable into the battery **first** then into the wall outlet **second**. The charging indicator light will first turn green then red, and remain red while charging while finally turning green when charging is

## Related Articles

[Battery Won't Turn On](#)