

# BATTERY CONNECTOR SPACER

## ASSEMBLY INSTRUCTION *for integrated battery*



- 1** Remove the battery



- 2** Remove the 4 screws of the battery connector



- 3** Lift the connector up out of the bracket, as far as it will go without too much force. Avoid pulling too hard on the connector, as this might damage the wires.  
On some occasions, it could be that the power wires are clamped or stuck between the motor and the frame. Then it will be necessary to partly disassemble the motor to free up the wires.



- 4** Take the special spacer (2120-WASHER-520) and hold it with the open side up.



- 5** Place the spacer underneath the connector in the recess of the connector bracket. It can be helpful to use needle nose pliers.

# BATTERY CONNECTOR SPACER


## ASSEMBLY INSTRUCTION *for integrated battery*



- 6** The spacer should fit in the recess easily and all the holes should line-up nicely.



- 7** Insert all screws and engage the threads a few turns.



- 8** Tighten the 4 screws to 1Nm.



- 9** Place the battery.



- 10** The bike is now ready for use.